

Limora Zentrallager
 Industriepark Nord 21
 D- 53567 Buchholz
 Tel: 49 (0) 2683-97 99 0
 E-Mail: Limora@Limora.com
 Internet: www.Limora.com

Filialen:
 • Aachen • Berlin • Bielefeld
 • Düsseldorf • Hamburg
 • Köln • Stuttgart

Fitting instructions for rear brake easy bleed

- The new, braided easy bleed kit comes complete with 2 new hoses, 2 banjo bolts, 4 sealing copper washers, 2 bleed nipples, a mount bracket assembly & fitting instructions.
- Fit bleed mount bracket (as photo – on opposite side to flexy feed from car)
- Route new bleed pipes as photo – (making sure no trapping, chafing or damage can occur)
- Remove existing bleed nipples and fit new pipes using 3/8" UNF banjo assemblies – being sure fitting/pipes are clear of calipers and cross-member.
- When fitting place the banjo bolts, through the washers and carefully finger tighten – being sure that the inner edge of the washers locate nicely through the banjo bolt without catching – this can be a problem if not observed. Fit plain washers to bolt head and special crushable washers to calliper side of pipe
- Finally zip tie the long bleed pipe (as photo) to the existing steel 3/16" brake pipes (short bleed pipe needs no extra securing)
- Bleed rear system in normal fashion & finally check tightness of all parts fitted & for any leakage.

