



Einbauanleitung für Stoßdämpferumrüstsatz / Installation instructions for Shock absorber conversion (ID 318163)

Mit diesem Umbausatz werden die die hinteren Hebelarm-Dämpfer des Jaguar XK120 durch Teleskopstoßdämpfer ersetzt. Hierbei muss die obere Befestigungsplatte an den Rahmen geschweißt werden (Abb 1). Die untere Platte des Umbausatzes ersetzt die Blattfederbefestigungsplatte und wird zusammen mit den, im Satz enthaltenen, U-Bolzen an der Hinterachse verschraubt (Abb 2).

Bitte beachten sie: Schweißarbeiten sind erforderlich. Dieser Umbau sollte während einer „Frame off“ Restauration durchgeführt werden.



Abb. 1 / ill. 1

This ingenious kit converts XK120 rear lever arm shock absorbers to modern dampers. By welding the upper plate to the frame (ill. 1) and sandwiching the lower pin mount where the spring attaches to the rear axle (ill. 2).

Please note: welding is required. This conversion is very difficult to carry out with the body in place. Easily performed during a body-off rebuild.



Abb. 2 / ill. 2

Limora Zentrallager
Industriepark Nord 21
D - 53567 Buchholz
Tel: +49 (0) 26 83 - 97 99 0
E-Mail: Limora@Limora.com
Internet: www.Limora.com

Filialen:
• Aachen • Berlin • Köln
• Düsseldorf • Stuttgart
• München